

5 N 1 LED DESK LAMP

WITH WIRELESS CHARGING FOR SMARTPHONES AND STANDS FOR APPLE WATCH® AND AIRPODS®



Item Number: XLP7-1008-BLK 855-999-8041 | WWW.XTREMECABLES.COM

V1 0 0823

INTRODUCTION

Thank you for choosing our 5 in 1 LED Desk Lamp. This versatile lamp combines the functionality of a lighting solution with convenient wireless charging capabilities for Qi-compatible devices. The foldable hinge and USB-A and USB-C watch charging ports facilitate convenient Apple Watch charging. This user manual will guide you through the setup process and provide instructions for optimal usage of the LED Lamp.

FEATURES

- Qi-Compatible wireless charging
- · Multiwhite light settings
- Clock display
- Alarm
- USB-C and USB-A smart watch charging ports
- · Wireless phone charging stand
- · AirPods stand
- Apple Watch charger holder

WIRELESS CHARGING CAUTIONS AND TIPS

- To prevent damage to the phone or the charger:
 - Remove metal cases, or cases with any magnet/metal components, from phone before charging.
 - Do not place metal objects on the charger during charging
 Oi wireless charges blanches with metallic finishes will
 - Qi wireless chargeable phones with metallic finishes will charge normally.
- Very thick phone cases can obstruct wireless charging.
 For effective charging, it may be necessary to reposition the phone or remove the case.
- Consider tuning off your phones vibrating notifications during charging, as vibrations may cause your phone to shift position on the charger and stop charging.
- For 15W phone charging: to ensure charging of some fully discharged 15W phones you may need to power off the LED light for some time if the phone will not remain charging.

GETTING TO KNOW YOUR 5 IN 1 DESK LAMP



1 USB-C + 1 USB Port In A Cable Storage Compartment for Watch Charging

INSTALLATION

- Carefully remove the LED Lamp and its accessories from the packaging.
- Unfold the lamp by extending the lamp arm and adjusting it to your desired height.
- Connect the lamp to a 20W Power Adapter (not included) using the included cable.
- To ensure proper operation, only use a 20W USB PD adapter and the supplied or equivalent 3A USB-C power cable.

OPERATION

Lighting

- To active the light: tap the Power button. The initial setting is cool white light at 50% brightness.
- To change the light modes: When the light is on, tap the Power button to change the light mode between cool white light, warm white light, and white light combination.
- To change the brightness level, tap and hold the Power button, the brightness with increase until it becomes 100%. Remove your finger and tap and hold again to decrease the light level until it becomes 10%.

Note: If you do not change for 5 seconds, the last setting will be automatically saved.

CLOCK SETTING

- To set the hour: Press and hold the Clock button, that is located to the left of the power key, until the hour digits start flashing.
 Presentedly to a the Clock button to change the hour digits. Standard the hour digits.
- Repeatedly tap the Clock button to change the hour digits. Stop tapping when you reach the desired hour setting and wait for the hour digits to stop flashing. The hour is now set.
- 3. To set the minutes: Press and hold the Clock button until the hour digits start flashing, lift your finger and press again until the minute digits start flashing.
- Repeatedly tap the Clock button to change the minute digits.
 Stop taping when you reach the desired minute setting and wait for the minute digits to stop flashing. The minutes are now set.

ALARM SETTING

- To set the hour: Press and hold the Alarm button, that is located to the right of the power key, until the hour digits start flashing.
 Repeatedly tan the Alarm button to change the hour digits. Ston
- Repeatedly tap the Alarm button to change the hour digits. Stop taping when you reach the desired hour setting and wait for the hour digits to stop flashing. The hour is now set.
- 3. To set the minutes: Press and hold the Alarm button until the hour digits start flashing, lift your finger and press again until the minute digits start flashing.
- Repeatedly tap the Alarm button to change the minute digits. Stop taping when you reach the desired minute setting and wait for the minute digits to stop flashing. The minutes are now set.
- When the alarm is set, the alarm icon will be displayed on the lower right side of the display.
- To check the alarm time setting, tap the alarm button. The alarm set time will be displayed for a few seconds before the display reverts to the clock time.
- To deactivate a sounding alarm, press the alarm button once.
 The alarm will stop sounding.
- To cancel the alarm setting, tap the alarm button three times.
 When the alarm setting is canceled, the alarm icon will no longer be displayed.

TO TURN OFF/ON THE DISPLAY

Press the clock and alarm key at the same time to turn off the clock display. Shortly press the clock key or the alarm key to reactivate the clock display.

CHARGING PHONE WIRELESS CHARGING

 With the lamp extended, place the phone over the wireless charging symbols, in the upright (portrait) or horizontal (landscape) orientation. The phone will begin to charge.

EARPHONE CASE STAND

 Place the earphones charging case on its holder ledge on the lower rear side of the lamp for easy access.

WATCH CHARGER SET UP

The 5 in 1 Lamp is equipped with an Apple watch charger holder where you can place your Apple watch charging puck (not included) to charge your Apple watch.

- Unfold the upper back hinge to reveal the smart watch charging holder. Open lower back panel door to expose the Smart Watch charging port compartment.
- Insert your watch charging puck's cable (not supplied) through the top back opening and thread it down to the charging compartment and plug its USB plug into the matching USB charging port.
- Pull down excess cable into the compartment and close the lower back panel door.
- ${\bf 4.\ \ Insert\ your\ watch\ charger\ into\ the\ circular\ watch\ charger\ holder}.$
- Place your watch securely on the watch charger and the charging will start.

MAINTENANCE AND SAFETY INFORMATION

children

- Read all the instructions before using the product, and use the product as intended.
- Disconnect the USB cable once the product is fully charged.
 Keep close supervision of this product if being used around
- Do not expose the product to rain or moisture, and do not use nearby water such as swimming pools, bathtubs, or sinks.
- Do not expose the product to heat sources, the sun, or leave in a hot vehicle.
- Do not place metal items on the surface of the product.
 Do not modify or try to use the product for a non-intended purpose.
- Do not cover the product with paper or other materials. Use in a well-ventilated area when charging.
- Wireless chargers generate heat when charging, and the wireless charger may temporarily stop charging if it gets too hot.
- Do not use if damaged or modified.
 Do not dissemble. There are no serviceable parts inside.
- Do not place magnetic strip cards or similar magnetically sensitive items between the phone and the charger. Wireless charging uses
- magnetic induction that could damage these items.
 Your phone will not charge wirelessly if it is connected to your computer's USB port, or if it's connected to a USB power adapter or
- other USB charging source.
 Do not use abrasive cleaning solvents to clean the unit.
- If you have a pacemaker or other such device, consult a physician before using this product.

FCC COMPLIANCE PART 18:

This device complies with part 18 of the FCC Rules. Operation is Subject To the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment to an outlet on a circuit different from
- that to which the receiver is connected. · Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not explicitly approved by the party responsible for compliance could void the user's authority to operate this equipment.

ONE YEAR WARRANTY

Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at customerservice@xtremecables.com

WHAT'S INSIDE: 5 in 1 Wireless Charging LED Desk Lamp 4ft Type-C Power Cable User Manual

SPECIFICATIONS:

Input: 9V/2A LED Power: 5W USB-C + USB Output: for Smart Watch Charging Wireless Charger Output: 5W-7.5W-10W-15W

